

DuPont™ Kalrez® W240

Perfluoroelastomer Parts

For Photovoltaic Wet Manufacturing Processes

Technical Information - December 2014

Product Description

DuPont™ Kalrez® W240 perfluoroelastomer parts are a black product for photovoltaic wet manufacturing processes requiring a wide range of chemical resistance. W240 provides an excellent combination of properties (resistance to acids/bases) and is the product of choice for wet processes as an upgrade from standard elastomers, i.e., FKM, NBR, EPDM, etc. A maximum service temperature of 230°C is suggested.

Features/Benefits

- Excellent resistance/low volume swell in a wide range of wet chemistries (acids/bases)
- Excellent resistance to amine-based chemistries versus standard elastomers
- Low metals content
- Very good mechanical strength/compression set properties

Typical Physical Properties¹

Color	Black
Hardness ² , Shore M (O-ring)	79
100% Modulus ³ , MPa	7.85
Tensile Strength at Break ³ , MPa	19.08
Elongation at Break ³ , %	159
Compression Set ⁴ , %	
70 hr at 204 °C	20
Maximum Service Temperature ⁵ , °C	230

Suggested Applications

- Wet etch tools
- Roller applications for wet inline tools
- Wet chemical management systems
- Filter, pumps, etc., for wet process applications

¹Not to be used for specification purposes

²ASTM D2240 and D1414 (AS568 K214 O-ring test specimens)

³ASTM D412 and D1414 (AS568 K214 O-ring test specimens)

⁴ASTM D395B and ASTM D1414 (AS568 K214 O-ring test specimens)

⁵DuPont proprietary test method

Chemical Resistance

For many applications, low volume swell/weight gain (change) of elastomers is critical for proper equipment operation. Excessive swell/weight gain (change) may cause permanent seal failure due to equipment hang-up, extrusion, etc. While other physical property testing may be needed to adequately define product performance in a particular application, volume swell/weight gain (change) is an excellent indicator of resistance to chemical attack. Table 1 provides chemical resistance (% volume swell) test data for Kalrez® W240 in various acids, bases, solvents and water. Table 2 compares the weight gain and volume swell of Kalrez® W240 versus standard FKM in an amine-based chemistry.



The miracles of science™

Table 1: Chemical Resistance, % Volume Swell^{1,2}

Chemical	Exposure Time	Temperature (°C)	% Volume Swell Kalrez® W240
Acetic Acid	70	100	4
Ammonium Hydroxide	70	100	4
Ethylene Diamine	70	90	5
Nitric Acid (70%)	70	85	1
Nitric Acid (70%)	672	85	3
Sulfuric Acid (98%)	70	150	3
Sulfuric Acid (98%)	672	150	5
Toluene	70	100	7
Toluene	672	100	6
Water	70	225	6

¹ ASTM D471 and D1414 (AS568 K214 O-ring test specimens)

² Please consult a Kalrez® Application Engineer to assess performance fit in your specific application

Table 2: Amine-Based Chemistry Resistance (MEA: DMSO 70:30 Mixture)^{1,2}

Property	% Volume Swell	
	Kalrez® W240	Competitive FKM K7
Weight Change, %	1.0	Test Specimen Melted
Hardness Change, pts.	-3	Test Specimen Melted
Surface Condition After Exposure	No Surface Degradation	Test Specimen Melted

¹ MEA = Monoethanol Amine; DMSO = Dimethyl Sulfoxide

² DuPont Proprietary Test Method: 14 days @ 80°C

Visit us at kalrez.dupont.com

Contact DuPont at the following regional locations:

North America
800-222-8377

Latin America
+0800 17 17 15

Europe, Middle East, Africa
+41 22 717 51 11

Greater China
+86-400-8851-888

ASEAN
+65-6586-3688

Japan
+81-3-5521-8484

The information provided in this data sheet corresponds to our knowledge on the subject at the date of its publication. This information may be subject to revision as new knowledge and experience becomes available. The data provided fall within the normal range of product properties and relate only to the specific material designated; these data may not be valid for such material used in combination with any other materials, additives or pigments or in any process, unless expressly indicated otherwise.

The data provided should not be used to establish specification limits or used alone as the basis of design; they are not intended to substitute for any testing you may need to conduct to determine for yourself the suitability of a specific material for your particular purposes. Since DuPont cannot anticipate all variations in actual end-use and disposal conditions, DuPont does not guarantee favorable results, makes no warranties and assumes no liability in connection with any use of this information. All such information is given and accepted at the buyer's risk. It is intended for use by persons having technical skill, at their own discretion and risk. Nothing in this publication is to be considered as a license to operate under or a recommendation to infringe any patent. DuPont advises you to seek independent counsel for a freedom to practice opinion on the intended application or end-use of our products.

CAUTION: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract that is consistent with DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative. You may also request a copy of DuPont POLICY Regarding Medical Applications H-50103-5 and DuPont CAUTION Regarding Medical Applications H-50102-5.

Copyright © 2014 DuPont. The DuPont Oval Logo, DuPont™, The miracles of science™, and Kalrez® are trademarks or registered trademarks of E.I. du Pont de Nemours and Company or its affiliates. All rights reserved.

(12/14) Reference No. KZE-A40016-00-A1214



The miracles of science™